




**AISIN WARNER
A40**

Pan Gasket BW55.GAS01
Filter BW55.FIL01



**AISIN WARNER
A40D**

Pan Gasket BW55.GAS01
Filter A43.FIL04



**AISIN WARNER
A42D, A43D, A44D**

Pan Gasket BW55.GAS01
Filter A43.FIL01




**AISIN WARNER
A40DL & A40DF**

Pan Gasket BW55.GAS01
Filter A43.FIL02



**AISIN WARNER
A40DE**

Pan Gasket BW55.GAS01
Filter A43.FIL03



**AISIN WARNER
A47DE**

Pan Gasket BW55.GAS01
Filter A43.FIL05