





RE4R01A
Pan Gasket RE4.GAS01
Filter SUB4.FIL03
19mm Neck



RE4R01A
Pan Gasket RE4.GAS01
Filter RE4.FIL01
Filter has 24.5mm Pick Up




RE4R01B
Pan Gasket RE4.GAS01
Filter RE4.FIL06




RL4R01A
Pan Gasket RE4.GAS01
Filter RE4.FIL05
25mm Neck




RE/RL4F02A
Pan Gasket RL4.GAS01
Filter RL4.FIL01
Transmission must be Disassembled to change
Filter



RE/RL4F03A/B
Pan Gasket RL43.GAS01
Filter RL43.FIL01



RE4R03A
4WD
Pan Gasket RE4.GAS02
Filter RE4.FIL01
Filter has 26mm Pick Up
Has been replaced by plastic design



RE4R03A
2WD
Pan Gasket RE4.GAS02
Filter RE4.FIL02
Filter has no Pick Up



JATCO RE4F04A
Pan Gasket RL4.GAS04
Filter RL4.FIL23
32mm Pick Up



JATCO RE4F04A
Pan Gasket RL4.GAS04
Filter RL4.FIL20
12.5mm Pick Up